




Installing *remote.it* on the SmartBee Hive


Want a more secure way to have remote access to your Hive? Try *remote.it*, a free third-party process that can provide access to your Hive without any network reconfiguration required. No more port forwarding. As with all approaches to providing more secure access to any web accessible resource this process requires a little more work to get setup and use. But the result is a connection to your Hive that does not increase exposure of your network as port forwarding can.

Your 2.1.xxx Hive has been pre-loaded with the capability to install this 3rd party process for gaining remote access to your Hive. Following the instructions below will get you started in using *remote.it* by installing the required software on your Hive and registering your Hive with *remote.it* process.


First, go to <https://remote.it> and create your personal account. Make sure you have subscribed to email alerts from your Hive, and you have access to that email during this process.



- 1.) Go to the Hive log in page and log in as you normally do.




- 2.) Go to Settings and navigate to the “Admin” page.
- 3.) Select “Remote Access”




4.) Click the “**Install Remote Access**” button.

5.) An email alert has been sent to your subscribed account. You will need this email to complete the process




6.) Log into your *remote.it* account.

7.) Click the blue button with the plus sign “+”.



8.) In the email you received find the “Claim Code” and copy into the Claim Code Box.

9.) Then click the green check mark



After a slight delay you should get an acknowledgement that your smartbee device has been registered.